



Compatibility list for digital cameras

ALDI

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Aldi Traveler Slimline X 4	Eneride E Min NP 900	650 mAh	3,7 V	365519
Aldi Traveler Slimline X 5	Eneride E Min NP 900	650 mAh	3,7 V	365519
Aldi Traveler Slimline X 6	Eneride E Min NP 900	650 mAh	3,7 V	365519
Aldi Traveler Superslim XS 7	Eneride E Min NP 900	650 mAh	3,7 V	365519

CANON

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Canon EOS 5 D	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268
Canon EOS 5 D Mark II	Eneride E Can LP-E 6	1500 mAH	7,2 V	303240
Canon EOS 5 D Mark III	Eneride E Can LP-E 6	1500 mAH	7,2 V	303240
Canon EOS 7 D	Eneride E Can LP-E 6	1500 mAH	7,2 V	303240
Canon EOS 10 D	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268
Canon EOS 20D	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268
Canon EOS 30 D	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268
Canon EOS 40 D	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268
Canon EOS 50 D	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268
Canon EOS 60 D	Eneride E Can LP-E 6	1500 mAH	7,2 V	303240
Canon EOS 300 D	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268
Canon EOS 350 D	Eneride E Can NB-2 LH	1000 mAh	7,4 V	303254
Canon EOS 400 D	Eneride E Can NB-2 LH	1000 mAh	7,4 V	303254
Canon EOS 450 D	Eneride E Can LP- E 5	1080 mAh	7,4 V	303205
Canon EOS 500 D	Eneride E Can LP- E 5	1080 mAh	7,4 V	303205
Canon EOS 550 D	Eneride E Can LP- E 8	1020 mAH	7,4 V	410221
Canon EOS 600 D	Eneride E Can LP- E 8	1020 mAH	7,4 V	410221
Canon EOS 1000 D	Eneride E Can LP- E 5	1080 mAh	7,4 V	303205

Canon EOS Rebel	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268
Canon Rebel XT	Eneride E Can NB-2 LH	1000 mAh	7,4 V	303254

Canon IXUS 30	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 40	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 50	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 55	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 60	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 65	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 70	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 75	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 80 IS	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 85 IS	Eneride E Can NB-6 L	1000 mAh	3,7 V	309463
Canon IXUS 90	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon IXUS 95 IS	Eneride E Can NB-6 L	1000 mAh	3,7 V	309463
Canon IXUS 100	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 105 IS	Eneride E Can NB-6 L	1000 mAh	3,7 V	309463
Canon IXUS 110 IS	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 115 HS	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 117 HS	Eneride E Can NB 4 L	650 mAh	3,7 V	309477



Compatibility list for digital cameras

Canon IXUS 120 IS	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 130 IS	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 200 IS	Eneride E Can NB 6 L	1000 mAh	3,7 V	309463
Canon IXUS 210 IS	Eneride E Can NB-6 L	1000 mAh	3,7 V	309463
Canon IXUS 220 HS	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 230 HS	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS 300	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon IXUS 300 HS	Eneride E Can NB-6 L	1000 mAh	3,7 V	309463
Canon IXUS 310 HS	Eneride E Can NB-6 L	1000 mAh	3,7 V	309463
Canon IXUS 330	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon IXUS 400	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon IXUS 430	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon IXUS 500	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon IXUS 500 HS	Eneride E Can NB-9 L	870 mAh	3,7 V	472962
Canon IXUS 510 HS	Eneride E Can NB-9 L	870 mAh	3,7 V	472962
Canon IXUS 800 IS	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon IXUS 850 IS	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon IXUS 860 IS	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon IXUS 870 IS	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon IXUS 900 TI	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon IXUS 960 IS	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon IXUS 970 IS	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon IXUS 980 IS	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon IXUS 990 IS	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon IXUS 1000 HS	Eneride E Can NB-9 L	870 mAh	3,7 V	472962
Canon IXUS 1100 HS	Eneride E Can NB-9 L	870 mAh	3,7 V	472962
Canon IXUS i	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS i7	Eneride E Can NB 4 L	650 mAh	3,7 V	309477
Canon IXUS SD 700 IS	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon IXUS V	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon IXUS V 2	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon IXUS V 3	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505

Canon PowerShot A 2200	Eneride E Can NB-8 L	700 mAH	3,7 V	410242
Canon PowerShot A 3000	Eneride E Can NB-8 L	700 mAH	3,7 V	410242
Canon PowerShot A 3100	Eneride E Can NB-8 L	700 mAH	3,7 V	410242
Canon PowerShot A 3300	Eneride E Can NB-8 L	700 mAH	3,7 V	410242

Canon Powershot D10	Eneride E Can NB-6 L	1000 mAh	3,7 V	309463
Canon Powershot D20	Eneride E Can NB-6 L	1000 mAh	3,7 V	309463

Canon PowerShot G1	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268
Canon PowerShot G2	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268
Canon PowerShot G3	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268
Canon PowerShot G5	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268
Canon PowerShot G6	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268
Canon PowerShot G7	Eneride E Can NB-2 LH	1000 mAh	7,4 V	303254
Canon PowerShot G9	Eneride E Can NB-2 LH	1000 mAh	7,4 V	303254
Canon PowerShot G10	Eneride E Can NB-7 L	850 mAh	7,4 V	303261



Compatibility list for digital cameras

Canon PowerShot G11	Eneride E Can NB-7 L	850 mAh	7,4 V	303261
Canon PowerShot G 12	Eneride E Can NB-7 L	850 mAh	7,4 V	303261

Canon PowerShot S 30	Eneride E Can NB-2 LH	1000 mAh	7,4 V	303254
Canon PowerShot S 40	Eneride E Can NB-2 LH	1000 mAh	7,4 V	303254
Canon PowerShot S 45	Eneride E Can NB-2 LH	1000 mAh	7,4 V	303254
Canon PowerShot S 50	Eneride E Can NB-2 LH	1000 mAh	7,4 V	303254
Canon PowerShot S 60	Eneride E Can NB-2 LH	1000 mAh	7,4 V	303254
Canon PowerShot S 70	Eneride E Can NB-2 LH	1000 mAh	7,4 V	303254
Canon PowerShot S 80	Eneride E Can NB-2 LH	1000 mAh	7,4 V	303254
Canon PowerShot S 90	Eneride E Can NB 6 L	1000 mAh	3,7 V	309463
Canon PowerShot S 100 Digital Elph	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon PowerShot S 100	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon PowerShot S 110	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon PowerShot S 200	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon PowerShot S 230	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon PowerShot S 300	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon PowerShot S 330	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon PowerShot S 400	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon PowerShot S 410	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505
Canon PowerShot S 500	Eneride E Can NB 1 LH	950 mAh	3,7 V	309505

Canon PowerShot SX 30 IS	Eneride E Can NB-7 L	850 mAh	7,4 V	303261
Canon PowerShot SX 200 IS	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon PowerShot SX 220 HS	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon PowerShot SX 230 HS	Eneride E Can NB-5 L	680 mAh	3,7 V	303247
Canon PowerShot SX 240 HS	Eneride E Can NB 6 L	1000 mAh	3,7 V	309463
Canon PowerShot SX 260 HS	Eneride E Can NB 6 L	1000 mAh	3,7 V	309463

Canon PowerShot Pro 1	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268
Canon PowerShot Pro 90 IS	Eneride E Can BP 511 A	1400 mAh	7,4 V	303268

CASIO

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Casio EXILIM Card EX-S 1	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM Card EX-S 10	Eneride E Casio NP 60	600 mAh	3,7 V	303282
Casio EXILIM Card EX-S 12	Eneride E Casio NP 60	600 mAh	3,7 V	303282
Casio EXILIM Card EX-S 100	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM Card EX-S 500	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM Card EX-S 600	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM Card EX-S 770	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM Card EX-S 880	Eneride E Casio NP 20	650 mAh	3,7 V	309512

Casio EXILIM EX-G 1	Eneride E Casio NP 80	660 mAh	3,7 V	373443
Casio EXILIM EX-H 5	Eneride E Casio NP 80	660 mAh	3,7 V	373443
Casio EXILIM EX-M 1	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM EX-M 2	Eneride E Casio NP 20	650 mAh	3,7 V	309512

Casio EXILIM Zoom EX-Z 1	Eneride E Casio NP 80	660 mAh	3,7 V	373443
--------------------------	-----------------------	---------	-------	--------



Compatibility list for digital cameras

Casio EXILIM Zoom EX-Z 2	Eneride E Casio NP 80	660 mAh	3,7 V	373443
Casio EXILIM Zoom EX-Z 5	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM Zoom EX-Z 8	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM Zoom EX-Z 11	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM Zoom EX-Z 12	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM Zoom EX-Z 16	Eneride E Casio NP 80	660 mAh	3,7 V	373443
Casio EXILIM Zoom EX-Z 19	Eneride E Casio NP 60	600 mAh	3,7 V	303282
Casio EXILIM Zoom EX-Z 20	Eneride E Casio NP 60	600 mAh	3,7 V	303282
Casio EXILIM Zoom EX-Z 21	Eneride E Casio NP 60	600 mAh	3,7 V	303282
Casio EXILIM Zoom EX-Z 25	Eneride E Casio NP 60	600 mAh	3,7 V	303282
Casio EXILIM Zoom EX-Z 28	Eneride E Casio NP 80	660 mAh	3,7 V	373443
Casio EXILIM Zoom EX-Z 60	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM Zoom EX-Z 65	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM Zoom EX-Z 70	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM Zoom EX-Z 75	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM Zoom EX-Z 77	Eneride E Casio NP 20	650 mAh	3,7 V	309512
Casio EXILIM Zoom EX-Z 80	Eneride E Casio NP 60	600 mAh	3,7 V	303282
Casio EXILIM Zoom EX-Z 85	Eneride E Casio NP 60	600 mAh	3,7 V	303282
Casio EXILIM Zoom EX-Z 90	Eneride E Casio NP 60	600 mAh	3,7 V	303282
Casio EXILIM Zoom EX-Z 150	Eneride E Casio NP 70	900 mAh	3,7 V	309519
Casio EXILIM Zoom EX-Z 250	Eneride E Casio NP 70	900 mAh	3,7 V	309519
Casio EXILIM Zoom EX-Z 150	Eneride E Casio NP 80	660 mAh	3,7 V	373443
Casio EXILIM Zoom EX-Z 280	Eneride E Casio NP 80	660 mAh	3,7 V	373443
Casio EXILIM Zoom EX-Z 330	Eneride E Casio NP 80	660 mAh	3,7 V	373443
Casio EXILIM Zoom EX-Z 550	Eneride E Casio NP 80	660 mAh	3,7 V	373443
Casio EXILIM Zoom EX-Z 800	Eneride E Casio NP 80	660 mAh	3,7 V	373443
Casio EXILIM High Speed EX-FS 10	Eneride E Casio NP 60	600 mAh	3,7 V	303282
Casio EXILIM EX-ZS 5	Eneride E Casio NP 80	660 mAh	3,7 V	373443
Casio EXILIM EX-ZS 100	Eneride E Casio NP 80	660 mAh	3,7 V	373443
Casio EXILIM EX-ZS 150	Eneride E Casio NP 80	660 mAh	3,7 V	373443

FUJIFILM

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Fujifilm FinePix AX 200	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix J 10	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix J 27	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix J 50	Eneride E Fuji NP 40	600 mAh	3,7 V	373485
Fujifilm FinePix J 100	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix J 110 W	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix J 150 W	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix J 1100	Eneride E Fuji NP 45	650 mAh	3,7 V	373513

Fujifilm FinePix F 20	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Fujifilm FinePix F 40 d	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Fujifilm FinePix F 47 fd	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Fujifilm FinePix F 50	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix F 50 fd	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix F 60 fd	Eneride E Fuji NP 50	750 mAh	3,7 V	373520



Compatibility list for digital cameras

Fujifilm FinePix F 70 EXR	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix F 80	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix F 100	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix F 100 fd	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix F 200 EXR	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix F 300 EXR	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix F 402	Eneride E Fuji NP 40	600 mAh	3,7 V	373485
Fujifilm FinePix F 455	Eneride E Fuji NP 40	600 mAh	3,7 V	373485
Fujifilm FinePix F 460	Eneride E Fuji NP 40	600 mAh	3,7 V	373485
Fujifilm FinePix F 470	Eneride E Fuji NP 40	600 mAh	3,7 V	373485
Fujifilm FinePix F 500 EXR	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix F 550 EXR	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix F 600 EXR	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix F 610	Eneride E Fuji NP 40	600 mAh	3,7 V	373485
Fujifilm FinePix F 650	Eneride E Fuji NP 40	600 mAh	3,7 V	373485
Fujifilm FinePix F 660 EXR	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix F 700	Eneride E Fuji NP 40	600 mAh	3,7 V	373485
Fujifilm FinePix F 710	Eneride E Fuji NP 40	600 mAh	3,7 V	373485
Fujifilm FinePix F 750 EXR	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix F 770 EXR	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix F 810	Eneride E Fuji NP 40	600 mAh	3,7 V	373485
Fujifilm FinePix F 811	Eneride E Fuji NP 40	600 mAh	3,7 V	373485

Fujifilm FinePix JV 100	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix JX 200	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix JX 280	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix JX 300	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix JX 370	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix JX 520	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix JX 550	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix JX 700	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix JZ 100	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix JZ 300	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix JZ 500	Eneride E Fuji NP 45	650 mAh	3,7 V	373513

Fujifilm FinePix Real 3D W3	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix S 100 FS	Eneride E Fuji NP 140	1050 mAh	3,7 V	373534
Fujifilm FinePix S 200 EXR	Eneride E Fuji NP 140	1050 mAh	3,7 V	373534

Fujifilm FinePix T 200	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix T 210	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix T 300	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix T 350	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix T 400	Eneride E Fuji NP 45	650 mAh	3,7 V	373513

Fujifilm FinePix V 10	Eneride E Fuji NP 40	600 mAh	3,7 V	373485
Fujifilm FinePix V 20	Eneride E Fuji NP 40	600 mAh	3,7 V	373485



Compatibility list for digital cameras

Fujifilm FinePix X 10	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix XP 10	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix XP 30	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix XP 50	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix XP 100	Eneride E Fuji NP 50	750 mAh	3,7 V	373520
Fujifilm FinePix XP 150	Eneride E Fuji NP 50	750 mAh	3,7 V	373520

Fujifilm FinePix Z 1	Eneride E Fuji NP 40	600 mAh	3,7 V	373485
Fujifilm FinePix Z 2	Eneride E Fuji NP 40	600 mAh	3,7 V	373485
Fujifilm FinePix Z 5	Eneride E Fuji NP 40	600 mAh	3,7 V	373485
Fujifilm FinePix Z 10 fd	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix Z 20 fd	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix Z 35	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix Z 37	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix Z 70	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix Z 90	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix Z 100 fd	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix Z 300	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix Z 700	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix Z 800	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix Z 900	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix Z 950	Eneride E Fuji NP 45	650 mAh	3,7 V	373513
Fujifilm FinePix Z 1000	Eneride E Fuji NP 45	650 mAh	3,7 V	373513

KONICA MINOLTA

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Konica Minolta Dimage A 1	Eneride E Pen D-LI 50	1400 mAh	7,2 V	303499
Konica Minolta Dimage A 2	Eneride E Pen D-LI 50	1400 mAh	7,2 V	303499
Konica Minolta Dimage E 40	Eneride E Min NP 900	650 mAh	3,7 V	365519
Konica Minolta Dimage E 50	Eneride E Min NP 900	650 mAh	3,7 V	365519
Konica Minolta Dynax 5D	Eneride E Pen D-LI 50	1400 mAh	7,2 V	303499
Konica Minolta Dynax 7D	Eneride E Pen D-LI 50	1400 mAh	7,2 V	303499

LEICA

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Leica D-Lux 1	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Leica D-Lux 2	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Leica D-Lux 3	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Leica C Lux 1	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Leica C Lux 2	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Leica C Lux 3	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Leica V-Lux 1	Eneride E Pan CGR-S 006	710 mAh	7,4 V	303359

MAGINON

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Maginon X 4	Eneride E Min NP 900	650 mAh	3,7 V	365519



Compatibility list for digital cameras

Maginon X 5	Eneride E Min NP 900	650 mAh	3,7 V	365519
-------------	----------------------	---------	-------	--------

MEDION

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Medion MD 8570	Eneride E Min NP 900	650 mAh	3,7 V	365519

MINOX

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Minox DC 4211	Eneride E Min NP 900	650 mAh	3,7 V	365519
Minox DC 5222	Eneride E Min NP 900	650 mAh	3,7 V	365519

NIKON

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Nikon Coolpix AW 100	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757

Nikon Coolpix 3700	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix 4200	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix 5200	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix 5900	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix 7900	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303

Nikon Coolpix L 16	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
--------------------	------------------------	---------	-------	--------

Nikon Coolpix P 3	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix P 4	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix P 50	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix P 80	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix P 90	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix P 100	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix P 300	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix P 310	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix P 500	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix P 510	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix P 5000	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix P 5100	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix P 6000	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303

Nikon Coolpix S 10	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix S 60	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
Nikon Coolpix S 70	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 80	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
Nikon Coolpix S 200	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
Nikon Coolpix S 210	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
Nikon Coolpix S 220	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
Nikon Coolpix S 225	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
Nikon Coolpix S 230	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
Nikon Coolpix S 510	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
Nikon Coolpix S 520	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540



Compatibility list for digital cameras

Nikon Coolpix S 550	Eneride E Pen D-LI 78	680 mAh	3,7 V	303506
Nikon Coolpix S 560	Eneride E Pen D-LI 78	680 mAh	3,7 V	303506
Nikon Coolpix S 570	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
Nikon Coolpix S 600	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
Nikon Coolpix S 610	Eneride E Nik EN EL 5	1000 mAh	3,7 V	303303
Nikon Coolpix S 610	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 610C	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 620	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 630	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 640	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 700	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
Nikon Coolpix S 710	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 1000	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 1100 pj	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 1200 pj	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 3000	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
Nikon Coolpix S 4000	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
Nikon Coolpix S 5100	Eneride E Nik EN EL 10	800 mAh	3,7 V	309540
Nikon Coolpix S 6150	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 6200	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 6300	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 8000	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 8100	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 8200	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 9100	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757
Nikon Coolpix S 9300	Eneride E Nik EN EL 12	1000 mAh	3,7 V	309757

Nikon D 40	Eneride E Nik EN EL 9	1000 mAh	3,7 V	303310
Nikon D 40 x	Eneride E Nik EN EL 9	1000 mAh	7,4 V	303310
Nikon D 50	Eneride E Nik EN EL 3e	1400 mAh	7,4 V	303296
Nikon D 60	Eneride E Nik EN EL 9	1000 mAh	7,4 V	303310
Nikon D 70	Eneride E Nik EN EL 3e	1400 mAh	7,4 V	303296
Nikon D 80	Eneride E Nik EN EL 3e	1400 mAh	7,4 V	303296
Nikon D 90	Eneride E Nik EN EL 3e	1400 mAh	7,4 V	303296
Nikon D 100	Eneride E Nik EN EL 3e	1400 mAh	7,4 V	303296
Nikon D 200	Eneride E Nik EN EL 3e	1400 mAh	7,4 V	303296
Nikon D 300	Eneride E Nik EN EL 3e	1400 mAh	7,4 V	303296
Nikon D 300 S	Eneride E Nik EN EL 3 e	1400 mAh	7,4 V	303296
Nikon D 700	Eneride E Nik EN EL 3e	1400 mAh	7,4 V	303296
Nikon D 3000	Eneride E Nik EN EL 9	1000 mAh	7,4 V	303310
Nikon D 5000	Eneride E Nik EN EL 9	1000 mAh	7,4 V	303310

OLYMPUS

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Olympus E-1	Eneride E Oly BLM 1	1400 mAh	7,2 V	303338
Olympus E-3	Eneride E Oly BLM 1	1400 mAh	7,2 V	303338
Olympus E-30	Eneride E Oly BLM 1	1400 mAh	7,2 V	303338
Olympus E-300	Eneride E Oly BLM 1	1400 mAh	7,2 V	303338
Olympus E-500	Eneride E Oly BLM 1	1400 mAh	7,2 V	303338



Compatibility list for digital cameras

Olympus E-510	Eneride E Oly BLM 1	1400 mAh	7,2 V	303338
Olympus E-520	Eneride E Oly BLM 1	1400 mAh	7,2 V	303338

Olympus FE 20	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 150	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 160	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 190	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 280	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 290	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 300	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 310	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 340	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 350 wide	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 360	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 4000	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 4010	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 5000	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 5030	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus FE 5050	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317

Olympus MD 160	Eneride E Oly BLM 1	1400 mAh	7,2 V	303338
----------------	---------------------	----------	-------	--------

Olympus μ 700	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 720 SW	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 725 SW	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 730	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 740	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 750	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 760	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 770 SW	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 790 SW	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 820	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 830m	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 840	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 850 SW	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 1010	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus μ 1020	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus μ 1030 SW	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus μ 1040	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 1050	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 1060	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 5000	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 7000	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 7010	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus μ 9000	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus μ 9010	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535



Compatibility list for digital cameras

Olympus μ Tough 6000	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus μ Tough 6010	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus μ Tough 6020	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus μ Tough 8000	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus μ Tough 8010	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535

Olympus SH-21	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
---------------	-----------------------	---------	-------	--------

Olympus SP 700	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus SP 800 UZ	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus SP 810 UZ	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535

Olympus SZ-10	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus SZ-11	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus SZ-14	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus SZ-20	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus SZ-30 MR	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus SZ-31 MR	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535

Olympus TG 310	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus TG 620	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus TG 810	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus TG 820	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus VH 210	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus VR 310	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus VR 325	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus VR 330	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Olympus VR 340	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535
Olympus VR 360	Eneride E Oly LI-50 B	770 mAh	3,7 V	507535

PANASONIC

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Panasonic Lumix DMC FS 3	Eneride E Pan DMW-BCE 10 /S 008	1000 mAh	3,7 V	303457
Panasonic Lumix DMC FS 5	Eneride E Pan DMW-BCE 10 /S 008	1000 mAh	3,7 V	303457
Panasonic Lumix DMC FS 20	Eneride E Pan DMW-BCE 10 /S 008	1000 mAh	3,7 V	303457

Panasonic Lumix DMC FX 01	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Panasonic Lumix DMC FX 07	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Panasonic Lumix DMC FX 8	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Panasonic Lumix DMC FX 9	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Panasonic Lumix DMC FX 10	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Panasonic Lumix DMC FX 12	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Panasonic Lumix DMC-FX 30	Eneride E Pan DMW-BCE 10 /S 008	1000 mAh	3,7 V	303457
Panasonic Lumix DMC-FX 33	Eneride E Pan DMW-BCE 10 /S 008	1000 mAh	3,7 V	303457
Panasonic Lumix DMC-FX 35	Eneride E Pan DMW-BCE 10 /S 008	1000 mAh	3,7 V	303457
Panasonic Lumix DMC-FX 37	Eneride E Pan DMW-BCE 10 /S 008	1000 mAh	3,7 V	303457
Panasonic Lumix DMC FX 50	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Panasonic Lumix DMC-FX 55	Eneride E Pan DMW-BCE 10 /S 008	1000 mAh	3,7 V	303457



Compatibility list for digital cameras

Panasonic Lumix DMC FX100	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Panasonic Lumix DMC FX 150	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Panasonic Lumix DMC-FX 500	Eneride E Pan DMW-BCE 10 /S 008	1000 mAh	3,7 V	303457

Panasonic Lumix DMC-FZ 7	Eneride E Pan CGR-S 006	710 mAh	7,4 V	303359
Panasonic Lumix DMC-FZ 8	Eneride E Pan CGR-S 006	710 mAh	7,4 V	303359
Panasonic Lumix DMC-FZ 28	Eneride E Pan CGR-S 006	710 mAh	7,4 V	303359
Panasonic Lumix DMC-FZ 30	Eneride E Pan CGR-S 006	710 mAh	7,4 V	303359
Panasonic Lumix DMC-FZ 50	Eneride E Pan CGR-S 006	710 mAh	7,4 V	303359

Panasonic Lumix DMC-TZ 1	Eneride E Pan CGA-S 007	1000 mAh	3,7 V	303450
Panasonic Lumix DMC-TZ 2	Eneride E Pan CGA-S 007	1000 mAh	3,7 V	303450
Panasonic Lumix DMC-TZ 3	Eneride E Pan CGA-S 007	1000 mAh	3,7 V	303450
Panasonic Lumix DMC-TZ 5	Eneride E Pan CGA-S 007	1000 mAh	3,7 V	303450
Panasonic Lumix DMC LX 1	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Panasonic Lumix DMC LX 2	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Panasonic Lumix DMC LX 3	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568



Compatibility list for digital cameras

PENTAX

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Pentax K 10 D	Eneride E Pen D-LI 50	1400 mAh	7,2 V	303499
Pentax K 20 D	Eneride E Pen D-LI 50	1400 mAh	7,2 V	303499
Pentax Optio A 10	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio A 20	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio A 30	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio E 85	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio H 90	Eneride E Pen D-LI 88	600 mAH	3,7 V	468440
Pentax Optio I 10	Eneride E Pen D-LI 88	600 mAH	3,7 V	468440
Pentax Optio M 30	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Pentax Optio M 40	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Pentax Optio M 50	Eneride E Pen D-LI 78	680 mAh	3,7 V	303506
Pentax Optio M 60	Eneride E Pen D-LI 78	680 mAh	3,7 V	303506
Pentax Optio P 80	Eneride E Pen D-LI 88	600 mAH	3,7 V	468440
Pentax Optio RZ 10	Eneride E Pen D-LI 92	770 mAh	3,7 V	507570
Pentax Optio RZ 18	Eneride E Pen D-LI 92	770 mAh	3,7 V	507570
Pentax Optio SV	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio S 1	Eneride E Pen D-LI 78	680 mAh	3,7 V	303506
Pentax Optio S 4i	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio S 4s	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio S 5	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio S 6	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio S 7	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio T 10	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio V 10	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Pentax Optio V 20	Eneride E Pen D-LI 78	680 mAh	3,7 V	303506
Pentax Optio WG-1	Eneride E Pen D-LI 92	770 mAh	3,7 V	507570
Pentax Optio WG 1-GPS	Eneride E Pen D-LI 92	770 mAh	3,7 V	507570
Pentax Optio WG-2	Eneride E Pen D-LI 92	770 mAh	3,7 V	507570
Pentax Optio WG-2 GPS	Eneride E Pen D-LI 92	770 mAh	3,7 V	507570
Pentax Optio WP	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio Wpi	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio W 10	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio W 20	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio W 30	Eneride E Oly LI-40B/42 B	660 mAh	3,7 V	303317
Pentax Optio W 60	Eneride E Pen D-LI 78	680 mAh	3,7 V	303506



Compatibility list for digital cameras

Pentax Optio W 80	Eneride E Pen D-LI 78	680 mAh	3,7 V	303506
Pentax Optio W 90	Eneride E Pen D-LI 88	600 mAH	3,7 V	468440
Pentax Optio WS 80	Eneride E Pen D-LI 88	600 mAH	3,7 V	468440

Pentax Optio X	Eneride E Pen D-LI 8	600 mAh	3,7 V	365540
Pentax Optio X 70	Eneride E Pen D-LI 92	770 mAh	3,7 V	507570

RICOH

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Ricoh Caplio CX-3	Eneride E Pen D-LI 92	770 mAh	3,7 V	507570
Ricoh Caplio CX-4	Eneride E Pen D-LI 92	770 mAh	3,7 V	507570
Ricoh Caplio R 3	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Ricoh Caplio R 4	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Ricoh Caplio R 6	Eneride E Pan DMW-BCE 10 /S 008	1000 mAh	3,7 V	303457
Ricoh Caplio R 7	Eneride E Pan DMW-BCE 10 /S 008	1000 mAh	3,7 V	303457
Ricoh Caplio R 8	Eneride E Pan DMW-BCE 10 /S 008	1000 mAh	3,7 V	303457
Ricoh Caplio R 10	Eneride E Pan DMW-BCE 10 /S 008	1000 mAh	3,7 V	303457
Ricoh Caplio R 30	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568
Ricoh Caplio R 50	Eneride E Pen D-LI 78	680 mAh	3,7 V	303506
Ricoh Caplio R 100	Eneride E Pan CGA S 005 E	1000 mAh	3,7 V	309568

ROLLEI

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Rollei dp 4200	Eneride E Min NP 900	650 mAh	3,7 V	365519
Rollei dp 5200	Eneride E Min NP 900	650 mAh	3,7 V	365519
Rollei dp 6200	Eneride E Min NP 900	650 mAh	3,7 V	365519

SAMSUNG

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Samsung ES 55	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
Samsung ES 60	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
Samsung ES 65	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung ES 70	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung ES 75	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung ES 80	Eneride E Sam SLB-11 A	1150 mAh	3,8 V	365533

Samsung EX 1	Eneride E Sam SLB-11 A	1150 mAh	3,8 V	365533
--------------	------------------------	----------	-------	--------

Samsung GX 10	Eneride E Pen D-LI 50	1400 mAh	7,2 V	303499
---------------	-----------------------	----------	-------	--------

Samsung IT 100	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
----------------	------------------------	---------	-------	--------

Samsung L 100	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
Samsung L 110	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
Samsung L 210	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
Samsung L 310 W	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526

Samsung MV 800	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
----------------	-----------------------	---------	-------	--------



Compatibility list for digital cameras

Samsung NV 9	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
--------------	------------------------	---------	-------	--------

Samsung PL 20	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung PL 50	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
Samsung PL 51	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
Samsung PL 55	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
Samsung PL 60	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
Samsung PL 65	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
Samsung PL 70	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
Samsung PL 80	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung PL 90	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung PL 100	Eneride E Sam SLB-07 A	500 mAh	3,7 V	410263
Samsung PL 120	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung PL 150	Eneride E Sam SLB-07 A	500 mAh	3,7 V	410263
Samsung PL 170	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung PL 200	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung PL 210	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412

Samsung ST 30	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung ST 45	Eneride E Sam SLB-07 A	500 mAh	3,7 V	410263
Samsung ST 50	Eneride E Sam SLB-07 A	500 mAh	3,7 V	410263
Samsung ST 60	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung ST 65	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung ST 70	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung ST 77	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung ST 88	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung ST 90	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung ST 93	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung ST 95	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
Samsung ST 500	Eneride E Sam SLB-07 A	500 mAh	3,7 V	410263
Samsung ST 550	Eneride E Sam SLB-07 A	500 mAh	3,7 V	410263
Samsung ST 600	Eneride E Sam SLB-07 A	500 mAh	3,7 V	410263
Samsung ST 1000	Eneride E Sam SLB-11 A	1150 mAh	3,8 V	365533
Samsung ST 5500	Eneride E Sam SLB-11 A	1150 mAh	3,8 V	365533

Samsung WB 150	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
Samsung WB 700	Eneride E Sam SLB-11 A	1150 mAh	3,8 V	365533
Samsung WB 710	Eneride E Sam SLB-11 A	1150 mAh	3,8 V	365533
Samsung WB 750	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
Samsung WB 850	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526
Samsung WB 1000	Eneride E Sam SLB-11 A	1150 mAh	3,8 V	365533
Samsung WB 2000	Eneride E Sam SLB-11 A	1150 mAh	3,8 V	365533
Samsung WB 5000	Eneride E Sam SLB-11 A	1150 mAh	3,8 V	365533
Samsung WB 5500	Eneride E Sam SLB-10 A	850 mAh	3,7 V	365526

Samsung WP 10	Eneride E Sam BP 70 A	670 mAH	3,7 V	468412
---------------	-----------------------	---------	-------	--------

SIGMA



Compatibility list for digital cameras

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Sigma SD 14	Eneride E Pen D-LI 50	1400 mAh	7,2 V	303499

SONY

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Sony Alpha 57	Eneride E Son NP-FM 500 H	1400 mAh	7,4 V	303555
Sony Alpha 65	Eneride E Son NP-FM 500 H	1400 mAh	7,4 V	303555
Sony Alpha 77	Eneride E Son NP-FM 500 H	1400 mAh	7,4 V	303555
Sony Alpha 100	Eneride E Son NP-FM 500 H	1400 mAh	7,4 V	303555
Sony Alpha 200	Eneride E Son NP-FM 500 H	1400 mAh	7,4 V	303555
Sony Alpha 300	Eneride E Son NP-FM 500 H	1400 mAh	7,4 V	303555
Sony Alpha 350	Eneride E Son NP-FM 500 H	1400 mAh	7,4 V	303555
Sony Alpha 500	Eneride E Son NP-FM 500 H	1400 mAh	7,4 V	303555
Sony Alpha 550	Eneride E Son NP-FM 500 H	1400 mAh	7,4 V	303555
Sony Alpha 580	Eneride E Son NP-FM 500 H	1400 mAh	7,4 V	303555
Sony Alpha 700	Eneride E Son NP-FM 500 H	1400 mAh	7,4 V	303555
Sony Alpha 850	Eneride E Son NP-FM 500 H	1400 mAh	7,4 V	303555
Sony Alpha 900	Eneride E Son NP-FM 500 H	1400 mAh	7,4 V	303555

Sony DSC H 10	Eneride E Son NP-BG 1	950 mAh	3,7 V	373660
Sony DSC H 20	Eneride E Son NP-BG 1	950 mAh	3,7 V	373660
Sony DSC H 50	Eneride E Son NP-BG 1	950 mAh	3,7 V	373660
Sony DSC H 70	Eneride E Son NP-BG 1	950 mAh	3,7 V	373660
Sony DSC-HX 10 V	Eneride E Son NP-BG 1	950 mAh	3,7 V	373660
Sony DSC-HX 20 V	Eneride E Son NP-BG 1	950 mAh	3,7 V	373660

Sony DSC T 99	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC T 110	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC TX 5	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC TX 7	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC TX 9	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC TX 10	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC TX 55	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC TX 100 V	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423

Sony DSC W 115	Eneride E Son NP-BG 1	950 mAh	3,7 V	373660
Sony DSC W 120	Eneride E Son NP-BG 1	950 mAh	3,7 V	376660
Sony DSC W 130	Eneride E Son NP-BG 1	950 mAh	3,7 V	376660
Sony DSC W 150	Eneride E Son NP-BG 1	950 mAh	3,7 V	376660
Sony DSC W 210	Eneride E Son NP-BG 1	950 mAh	3,7 V	376660
Sony DSC W 220	Eneride E Son NP-BG 1	950 mAh	3,7 V	376660
Sony DSC W 270	Eneride E Son NP-BG 1	950 mAh	3,7 V	376660
Sony DSC W 290	Eneride E Son NP-BG 1	950 mAh	3,7 V	376660
Sony DSC W 300	Eneride E Son NP-BG 1	950 mAh	3,7 V	373660
Sony DSC W 310	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC W 320	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC W 330	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC W 350	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC W 360	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423


eneride®

Compatibility list for digital cameras

Sony DSC W 380	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC W 390	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC W 510	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC W 520	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC W 530	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC W 570	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC W 610	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC W 630	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC W 690	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC WX 1	Eneride E Son NP-BG 1	950 mAh	3,7 V	373660
Sony DSC WX 5	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC WX 7	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC WX 50	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423
Sony DSC WX 100	Eneride E Son NP-BN 1	600 mAH	3,7 V	479423

VOIGTLÄNDER

Camera model	Suitable Eneride battery pack	Capacity	Voltage	Art-Nr.
Voigtländer Vitrus D 4	Eneride E Min NP 900	650 mAh	3,7 V	365519
Voigtländer Vitrus D 5	Eneride E Min NP 900	650 mAh	3,7 V	365519
Voigtländer Vitrus D 6	Eneride E Min NP 900	650 mAh	3,7 V	365519
Voigtländer Vitrus D 500	Eneride E Min NP 900	650 mAh	3,7 V	365519
Voigtländer Vitrus D 600	Eneride E Min NP 900	650 mAh	3,7 V	365519
Voigtländer Vitrus S 5	Eneride E Min NP 900	650 mAh	3,7 V	365519